

de Montageanleitung
en Mounting instructions
fr Instructions de montage
sv Monteringsinstruktion
nl Montage-aanwijzing
it Istruzioni di montaggio
fi Asennusohje
es Instrucciones de montaje

no Montasjeanvisning
da Monteringsvejledning
pl Instrukcja montażu
cs Návod k montáži
sk Návod na montáž
hu Telepítési leírás
el Οδηγίες Εγκατάστασης
sr Uputstva za montažu


hr Uputstva za montažu
sl Navodila za montažo
ro Instrucțiuni de montare
ru Инструкция по монтажу
bg Инструкция за монтаж
tr Montaj talimatları
pt Instruções de montagem



QFP910
 CE 0678





2732Z08




2732Z06





2732Z02



2701Z13




2732M01




2701M01a



▶ min 60 mm



2702M01




2732Z01




2732Z09


A



2732Z03




2732Z04




2732Z07


B ①





② a)




b)




③




④ a)




b1)




④ b2)




⑤




⑥



⑦




C




LR6 (AA) 1.5 V


①




②



③



④



⑤

