










de Montageanleitung	es Instrucciones de montaje
en Mounting instructions	nl Montage-aanwijzing
fr Instructions de montage	da Monteringsvejledning
it Istruzioni di montaggio	sv Monteringsinstruktion

SSA955

CE 0678







48P4201




2700212

Siemens VDN., VEN., VUN..
 Siemens VD., VE., VU..
 Siemens VPD...VPE
 Siemens 2T../A
 Honeywell MNG
 Cazzaniga
 Heimeier
 TA
 Finimetall
 Oventrop M30x1.5
 Junkers
 Beulco Verteiler M30x1,5




2700213


AV51 Beulco M30x1,0
 AV52 Comap
 AV53 Danfoss RA-N (RA2000)
 AV54 Danfoss RAVL
 AV55 Danfoss RAV
 AV56 Giacomini
 AV57 Herz
 AV58 Oventrop M30x1.0
 AV59 Vaillant
 AV60 TA
 AV61 Markaryd
 AV100-MLG Siemens Radiagyr




2700201




2700202



2700203



2700204



2700205